

Ducati Streetfighter 2009-2015 Fender Eliminator Kit

Parts List

- x1 License plate holder
- x1 Block off plate
- x1 License plate LED light
- x1 License plate light adapter harness
- x4 6x12mm allen bolts
- x4 6x16mm allen bolts
- x8 6mm washers
- x4 6mm nylon lock nuts
- x2 OEM signal adapters
- x2 Aftermarket 10mm signal adapters

Recommended parts

- Loctite or thread sealer
- Electrical tape

1. Remove rear fender. 7 bolts to remove the lower section, then 2 more bolts to remove the upper section. These bolts will no longer be needed.

2. Inside fender is the harness for the turn signals and license plate plug, unplug those and feed the wires back through up the under tail. Leave the Ducati yellow and black wires for the license plate light hanging out.

3. Install the block off plate first using two M6x16 bolts and washers into the front two holes. Apply loctite or thread sealer on the threads but do not tighten them all the way.

4. Install the license plate holder using the remaining two M6x16 bolts and washer also applying loctite or thread sealer. Do not tighten.

5. Attach the LED license plate light to plate holder. Feed wires through rear hole. Attach adapter harness to LED plate light (Black>Black wire and Red>White wire) and plug it back into bike removed from step 2. Ducati Yellow>Red and Ducati Black>Black. Use electrical tape to seal the connectors. Feed the access slack back into the chassis. **WARNING: DO NOT TURN THE KEY UNTIL ELECTRICAL TAPE IS APPLIED. YOU MAY BLOW A FUSE.**

6. Tighten all four M6x16 bolts

7. Mount license plate to plate holder using four 6x12mm bolts, washers, and lock nuts from this kit.

8. Optional: Mount OEM or aftermarket turn signal adapters to license plate mounting holes on plate holder using two/four 6x12mm allen bolts, washers, and nuts. Install OEM or aftermarket turn signals onto adapter and route wires through rear hole of the fender hole block plate and plug into appropriate plug removed from step 2. Aftermarket signals may require wiring. Refer to illustration on right to mount factory signals.

9. Check all lighting

