

Ducati Multistrada 2010-2014 Fender Eliminator Kit

Parts List

- x1 License plate holder
- x1 Cover plate
- x1 License plate LED light
- x1 License plate adapter harness
- x4 6x12mm allen bolts
- x4 6mm washers
- x4 6mm nylon lock nuts
- x6 Plastic spacers
- x2 5x20mm allen bolts
- x2 5mm washers
- x1 Foam padding
- x2 Factory Ducati Signal Adapter Kit
- x2 Aftermarket 10mm signal adapters

Optional

Loctite or thread sealer

1. Remove rear fender (4 bolts from underneath). Retain these bolts for re-installation later. Unplug harness connecting fender to bike. Unplug tail light.

2. Separate factory fender in half and disconnect rear turn signals and license plate light. This harness will be used later. Unbolt tail light, these bolts will not longer be used.

3. Attach LED license plate light to plate holder and attach adapter harness to the LED plate light.

4. Peel and stick the foam padding ontop the cover plate. See illustration on right.

5. Using two (2) M5x20mm bolts, plastic spacers and M5 washers mount the tail light to the cover plate. Use a drop of loctite or thread sealer on these bolts.

Optional: Attach turn signals, see below

6. Plug the harness removed from Step 2 back to the bike. Plug in the license plate light and tail light to the bike while mounting the license plate holder to the cover plate to the under tail using 4 bolts removed in step 1. Make sure to insert spacer between cover plate and under tail. Use a drop of loctite or thread sealer on these bolts. See illustration.

7. Mount license plate to plate holder using four 6x12mm bolts, washers, and lock nuts from this kit.

Installing with factory rear turn signals

1. Remove the factory turn signals off the factory rear fender. Remove the rubber necks off the turn signals (1 bolt - retain bolt for mounting later). See illustration to right for mounting to the turn signal bracket

2. Mount the entire assembly behind the license plate holder using same holes for the license plate

3. Route the wires through the square opening and plug it back into the left and right turn signal plugs. 'DX' = Right and 'SX' = Left

Installing with aftermarket 10mm hole mount turn signals

1. Mount the 2 aftermarket turn signal adapters to the license plate holder upper hole.

2. Mount the aftermarket 10mm hole mount turn signals to adapter

3. Run the wires through the square opening and wire it to the bike

