

Fender Eliminator Kit Low Profile for 2020-2023 Ducati Streetfighter V4/V4S

Part No. FE-D20SFV4-LP

Parts List

x1 Plate Holder	x5 M5x12mm allen bolts
x1 Cover Plate	x4 M6x16mm allen bolts
x1 Wedge Bracket	x5 M5 washers
x1 License plate LED light	x4 M6 large OD washers
x1 License light adapter harness	x4 M6 nylon lock nuts

Required

T20 Torx bit
Loctite or thread sealer

1. Remove lower half of factory rear fender (4 T20 Torx bolts from underneath) and carefully lower down
2. Unplug left and right turn signals connectors as well as the license plate light connector, pop off and cut the wire harness holder cable tie to completely drop the lower half
3. Remove upper half of factory fender (2 bolts from underneath) then pull down and slide forward. Un-route the wire harness through to completely remove
4. Tuck the excess harness slack back into the undertail, leaving exposed the license plate light plugs. Note this kit does not come with brackets for mounting turn signals. An integrated tail light or other external signals required.
5. Mount the Wedge Bracket to the under tail by inserting into the rearward rubber grommet and secure using two (2) M5x12mm bolts and M5 washers. Ensure the proper direction the welded nuts protrudes on the top side. Apply a drop of Loctite or thread sealer on these bolts. Ensure the license plate light plug is protruding forward of the Wedge Bracket.
6. Mount the LED license plate light to the plate holder making sure the LEDs are facing downwards to the license plate. Feed the black/white wires through the Feed Hole on the Cover Plate and attach the adapter harness white>yellow and black>blue.
7. Plug in the LED license plate light to the bike and mount the Plate Holder to the Cover Plate to the Wedge Bracket using three (3) M5x12mm bolt and M5 washers. Apply a drop of Loctite or thread sealer on these bolts. Make sure to align the corresponding holes on the Plate Holder to the Cover Plate/Wedge Bracket before tightening. See illustration below
8. Mount the license plate to the Plate Holder using four (4) M6x16mm bolts, M6 large OD washers and M6 lock nuts
9. Turn on the bike and verify light functionality

