

Triumph Bonneville/Thruxton/Scrambler Café Conversion Fender Eliminator w/ LED Tail Light

[version 1.2]

Parts List

x1 Belly pan
 x1 Tail light mount
 x1 License plate holder
 x1 LED tail light
 x1 Universal resistors (pair)
 x1 Tail light harness adapter
 x4 M6x16mm bolts
 x2 M6x20mm bolts
 x2 M6x25mm bolts
 x8 M6 nylon lock nuts
 x4 M6 washers
 x4 M6 large OD washers
 x4 M8x12mm bolts
 x4 M8 washers
 x2 Aftermarket signal adapter

1. Remove the seat
2. Unplug the tail light/turn signal harness
3. Remove the rear fender (4 bolts from the top) and carefully drop down
4. Mount the belly pan to the chassis using (2) M6x25mm bolts in the front holes and (2) M6x20mm bolts in the rear holes with the corresponding M6 washer and lock nut
5. Assemble the LED tail light to the license plate holder to the tail light mount using the supplied washer and lock nut that comes with the tail light. Route the wire through the center opening before assembly
6. Mount the assembly from step 4 to the chassis using (4) M8x12mm bolts and washers
7. Route the tail light wire through the center hole on belly pan, attach it to the tail light adapter harness and plug it back into the bike. Connect as follows: Red1>Red, Red2>Green, White>White, Black>Black, Blue>Blue and Yellow>Yellow
8. Mount the license plate to the plate holder using the (4) M6x16mm bolts, M6 large OD washers and M6 lock nuts
9. Install seat and check that all lights are functional

Optional: Install aftermarket stalk-type in-hole turn signals

Attach the signal adapters to the upper holes of the backside of the license plate holder, then install the turn signal

