

Motodynamic™ Resistor Bypass Harness

Part Number: WH-NR-H02, WH-NR-Y02, WH-NR-K02

Installing the Motodynamic™ Resistor Bypass Harness assumes that an LED compatible flasher relay is already installed on the bike and that the flash rate is at the normal rate of speed

Step 1: The Resistor Bypass Harness will install in place of the tail light subharness. This subharness comes included with each Motodynamic sequential LED tail light and will NOT be used.

Step 2: Plug the Resistor Bypass Harness' blue and yellow wire to the tail light's blue and yellow wire respectively, insulate with green cover

Step 3: Plug the other end of the Resistor Bypass Harness to the bike's rear left and right turn signal output connectors.

Sample Illustration

